

**How to fill water:**

1. Before filling water, please pull out the plug first.
2. Set the steam control to the minimum position.
3. Pull down the cover of water filling mouth, then fill water.
4. Pull up the cover of water filling mouth, put the iron on the level way.

**How to dry clean:**

1. Turn the temperature control to "min" position, turn the steam control to minimum position, and put the plug into the socket.
1. Turn the temperature control to the suitable position which the ironed clothes required, the indicator bulb will light up, then put the iron on the smooth and stable place vertically.
2. After the indicator goes out, you can begin to iron.

**How to spray:**

Press the spraying button, water will be sprayed out from the spraying nozzle. At that time, you should keep enough water in the water tank.

**How to iron with steam:**

1. Fill water in the water tank.
2. Use steam ironing, turn the steam control to minimum position and set the temperature control at the ". ", ". ." or ". ." position.
3. After the indicator goes out, turn the steam control to the maximum position, steam will be sprayed, ironing can start.
4. After ironing complete, turn the temperature control to the "min" position, pull out the plug, pour out the remaining water, turn the steam control to minimum position.

**How to use bursting steam:**

Set the temperature control at the "... " position, then press down the bursting steam button, the base plate will spray out bursting steam.

Attention: Bursting steam must be used in steam ironing (The temperature control must be turned to the steam area).

**How to use self clean:**

Set the temperature control to the maximum position, press the self clean button, strong steam will be sprayed, ironing can self clean (Sure the water tank has enough water).

**Attentions:**

1. Please read the owner's manual before use the product.
2. Use the distilled or boiled water only. Do not fill in with any other liquid except water.
3. Unplug the iron when you leave it, even for a short time and put it in a place not within the reach of children.
4. When filling water or pouring out remaining water. Please pull out the plug first.
5. After using, turn the steam control to minimum position, turn the temperature control to "min", pull out the plug, and put the iron on the smooth and stable place vertically.

**Cautions:**

1. Make sure that the applied voltage is same as the rating voltage, and the socket has effective earth connection.
2. With any malfunction problem, send it to a qualified person for repair. Do not repair it yourself.
3. This iron is for household only.
4. Do not immerse the iron into any liquid for cleaning.
5. Do not touch the hot metal part, hot water, or steam to avoid scalding.
6. This appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to