

## USAGE :

1. Please check before you use


A. The heating wire is not damaged

B. Please do not use the socket lower than 230V/10A for fear of any accident.

2. Use the heater on the flat place. Do not put on an uneven place as the topple switch will be in an abnormal position and the heater will not work when it is turned on.

3. If you stop using heater, turn the power switch to the " " position, then put of the plug.

4. If you want to move the heater, please turn off the power switch, then put of the plug, and hang on the handle on the back of the heater.



## NOTES :

1. Strictly avoid to use the heater near the combustibles, explosive objects, things easy to be deformed or deteriorate, and where full of dust.

2. Strictly avoid to use the heater where it is easy to topple.

3. Strictly avoid to stem the small hole on the heater and insert anything into the machine. Especially for children for fear of shock.

4. When the heater toppled or the topple switch is not working regularly caused by any other reason, strictly avoid to push the topple switch for forcing use.

5. Strictly avoid to use the heater in the place of rainfall.

6. Because the heater heated by infrared ray. When using for a long time, the temperature of the things face to the heating element will rise quickly, Strictly prohibit to place the heating side of the heater direct to the infant.

7. There is slight sound when turned on or off, which is normal due to the material expanding when heated and contract when cooled, please do not be worried.

8. Strictly avoid to use the heater when it is covered.

9. Strictly avoid to plug-in or off the plug instead of turn on or off the power switch.

10. Do not locate the heater under or direct at the socket.

11. Strictly avoid to use the same socket with other big power appliance.

12. Please put off the plug when not in use.

13. If there is something wrong with heater, please turn off the machine, put off the plug immediately and send for repair to service center.

14. The heating wire used is treated by a special way, it has a long life, please do not use any other heating wire in place of it.

15. Strictly avoid to use or lengthened electric wire and movable socket.

## MAINTENANCE:

1. Please make sure that the plug should be put off before cleaning the heater.

2. Strictly prohibit to use water to wash the heater, It can be cleaned by a piece of soft damp cloth with a little natural detergent.. Please do not use other solvent like gasoline.

3. The machine must be used or stored after cooled and dried completely.

4. If stop using heater, please put off the plug from the socket, and store it in the dry place with a rustproof polybag, original packing is favoured.