

Please read these instructions before operating and retain for future reference.

## **SAFETY INSTRUCTIONS**

1. Do not run the grinder if operating conditions are not normal. In case of any fault rush to your nearest authorised Maharaja Whiteline dealer. Do not attempt to repair it yourself.
2. Always keep the wet grinder away from heat sources.
3. Always keep the wet grinder clean and dry.
4. Always use the wet grinder as per instruction in this manual.
5. Disconnect the wet grinder after every use from mains.
6. Lift wet grinder from its base only.
7. Clean drum and stones assembly after every use.
8. Close supervision is necessary when wet grinder is in operation.
9. Store wet grinder in its carton box/covered when not in use for a long time.
10. Don't run wet grinder empty.
11. Don't put your hand in wet grinder when in operation.
12. Don't pour water on wet grinder for cleaning. Please use damp sponge for cleaning.
13. Don't lift wet grinder when in operation.
14. Don't use any attachment other than provided with wet grinder.
15. Don't insert any sharp objects in slits, it may damage internal parts.