


# MAHARAJA —WHITELINE—

*Life gets easier*




**BLOSSOM**  
(RED, SAFFRON, BLUE, GREEN)  
Dry Iron

## INSTRUCTION MANUAL

## FEATURES

1. Swivel
2. Sole plate
3. Pilot light
4. Temperature selector
5. Main lead
6. Heel rest



Please read these instructions before operating and retain for future reference.

## SAFETY INSTRUCTIONS

1. It is important that the iron is always supervised while it is switched on. Never leave the appliance unattended while it is connected to the main supply or on the ironing board.
2. Children should never be allowed to operate the iron. Keep children away from this appliance.
3. The iron gets very hot in use. Burns can occur from touching the hot parts of the appliance, therefore touch handle and knob only.
4. Make sure that the main lead is not touching the hot parts of the iron.
5. Always unplug the iron from the main supply socket.
  - When it is not in use.
  - In the event of malfunction during use.
  - Before cleaning the appliance.
6. Never unplug the appliance from the main supply socket by pulling the main lead. Take care that the main lead does not trail over the front of the work surface.
7. Repair of electrical appliance must only be performed by the skilled personnel. Improper repairs can result in considerable hazards for the user.
8. In case the iron fails to operate or is damaged, please contact an authorised service centre for all repairs. Ask your retailer for the address of an authorised centre.
9. In case the appliance is misused or operated in any manner other than described in these instruction for use, no liability will be under taken for possible damage.

## OPERATING INSTRUCTIONS

1. Make sure that the applied voltage is same as the rating voltage and the socket has effective earth connection.
2. This iron is for household only.
3. Do not touch the hot metal part, avoid scalding.

### Hints on Ironing

1. Always check first if the label with the ironing instruction is attached to the article to be ironed. Follow the ironing instruction as per label. Sort the garments into groups relating to the international dot symbols or to the type of fabric

#### FABRIC GUIDE

- Synthetic fiber (lowest setting)
  - Silk, wool (medium setting)
  - Cotton, linen (highest setting)
2. Always begin with the fabrics which require the lowest setting.
  3. Before ironing sensitive fabrics check the material by ironing a small hidden part of the article to see whether it is sensitive to heat or not.
  4. It is best to iron the garments when they are still a little damp. Extremely dry garments are difficult to iron.
  5. Always position the iron on its heel rest when you interrupt ironing

## Ironing

1. Position the iron on its heel rest 6 and connect it to main supply socket.
2. Turn the temperature selector 4 to the desired setting (relating to the type of the fabric.)
3. When the pilot light goes off and glows again you can start ironing.
4. The pilot light will cycle on and off during ironing .This has no effect on the ironing.
5. If you set the temperature control to the lower setting after ironing at the high temperature, do not recommence ironing before the pilot light glows again.
6. When ironing is finished, unplug the appliance from the main supply socket

## Cleaning and Maintenance

1. Before cleaning the iron, always make sure that the plug has been removed from the main supply socket.
2. Allow the iron to cool down before cleaning.
3. Never immerse the iron in water or liquid.
4. Wipe the iron with a soft and dry cloth.

## Occasional care of sole plate

1. Apply a small amount of paraffin to the sole plate 2 while the iron is still slightly warm, Remove the residues with a soft cloth.
2. To remove residue of starch, greases, etc..., wipe the sole plate 2 with the damp cotton to which a small amount of vinegar may be added if required.
3. Do not use harsh abrasive cleaners.
4. Do not place the iron with the sole plate on to rough surface.

**Storage :-** Always store the iron on its heel rest 6.

## TECHNICAL DATA

Wattage : 1000 watts  
Power supply : 240 volts/50Hz

FOR BIS CERTIFICATION DETAIL SEE"  
web site : [www.bis.org.in](http://www.bis.org.in)

## WARRANTY TERMS AND CONDITIONS

The Company offers 2 year product warranty, for repairing or replacing parts, free of cost against defect in manufacturing functional part subject to the following terms and conditions.

1. This warranty is valid only if this card is duly signed and stamped by our dealer and is produced along with the original customer's copy of the purchase bill.
2. Warranty period starts from the date of purchase from our authorized dealer only.
3. The Appliance has to be used with all normal care and maintenance and in accordance with instructions for use, recommended by the company, as enumerated in the instruction manual.
4. The Appliance should not be repaired, tampered or altered by any agency or person other than an authorised company personnel or their service centers.
5. Plastic and glass parts, which are breakable, are not covered under this warranty.
6. The Appliances subject to normal wear & tear, misuse, neglect, accident including technical breakdown etc. or non compliance of the instructions given in the instruction manual, improper installation is not covered by this warranty.
7. The customer is responsible for bringing the defective product to the service centre/manufacture for servicing and collecting the same at his/her own cost.
8. The Appliance is meant for domestic use only.
9. Parts repaired or replaced under this warranty are warranted only for the remainder of the original warranty period, that is no fresh warranty period shall commence for the said replaced/repaired part.

10. Liability under terms of warranty is limited to the value of the repairs/replacement of the parts found to be defective within the warranty period. All parts may have been replaced shall have been replaced shall become the property of the company.

11. Under the terms of warranty, free service will be provided only within the municipal limits of the cities/towns where the company has its branches or authorized representatives. Service outside the municipal limits specified above will be provided after charging the actual to and fro traveling and incidental expenses, as prevailing from time to time.

12. The decision of the company is final and binding on all matters arising out of this warranty.

13. This warranty is issued at Delhi, and courts at Delhi shall have exclusive jurisdiction over matters by or following from this warranty. In case of any dispute, arising out of this the same shall be settled by an Arbitrator, In accordance with the provisions of Arbitration and conciliation Act, 1996.

WARRANTY CARD	
Model No	DI-113, Serial No. .... DI-114, DI-115, DI-116
C.M.No. ....	Date of Sale. ....
Owner's Name & Address. .... ..... .....	
Tested By. ....	Remarks. ....
AUTHORIZED DEALER/FRANCHISEE	



**MAHARAJA  
SERVICE APP**

COMPANY'S AUTHORIZED PRICE LIST FOR SPARES AVAILABLE WITH SERVICE FRANCHISEE

[www.maharajawhiteline.com](http://www.maharajawhiteline.com)

Follow us on :   

**Marketed by:**

Groupe SEB India (P) Ltd.

C-67, 3rd Floor,

DDA Sheds, Okhla Phase1, New Delhi-110020, India

**Quality Control No. HP / 14 / 001 / 0081**

**For customer feedback and complaints,  
please contact:**

**Service Executive :**

Groupe SEB India (P) Ltd.

C-67, 3rd Floor,

DDA Sheds, Okhla Phase1, New Delhi-110020, India

Tel : 011-43684999, 011-33684999, e-mail: maharajacare@groupeseb.com