# MAHARAJA —WHITELINE—

MIXER GRINDER

INSTRUCTION MANUAL

#### **IDENTIFICATION OF REPRESENTATIVE PARTS**











#### **MAXIMUM JAR CAPACITY**

JAR	TYPES OF JAR	CAPACITY		DRY CAPACITY (Rated) Max.
A2	Blender Jar	2.0 / 1.5 L	0.8 / 0.6 L	NA
A3	Wet Grinder (Liquidizer) Jar	1.5 L	0.6 L	NA
A4	Dry Grinder Jar	1.0 L	NA	0.4 L
A4	Dry Grinder Jar	0.7 L	NA	0.3 L
A5	Multi mix (Chutney)	0.4 L	0.16 L	0.2 L

A1- Basic Unit Note: \*\*(Jars Types) & \*(Jar Capacities) are model specific

#### STANDARD RECIPIES

S.NO	RECIPE	TYPES OF JARS	QUANTITY	TIME
		A3	For: 500 & 550W:  Urad Dal - 200g + 450ml Water soaked for 12hrs. As and when needed 90ml water can be added.  Parboiled Rice - 200g + 225ml Water soaked for 12hrs. As and when needed 45ml water can be added.	
		A3	For: 600W:  Urad Dal - 225g + 506ml Water soaked for 12hrs. As and when needed 101ml water can be added.  Parboiled Rice - 225g + 253ml Water soaked for 12hrs. As and when needed 51ml water can be added.	
1	Wet Grinding	A3	For: 650W: Urad Dal -250g + 563ml Water soaked for 12hrs. As and when needed 113ml water can be added. Parboiled Rice - 250g + 282ml Water soaked for 12hrs. As and when needed 56ml water can be added.	2 min
		А3	For: 750W: Urad Dal - 300g + 675ml Water soaked for 12hrs. As and when needed 135ml water can be added. Parboiled Rice - 300g + 338ml Water soaked for 12hrs. As and when needed 68ml water can be added.	
2	Milk Shake	A2/A3	For 2.0L / 1.5L Jar Capacity : 500ml milk + 50g ice cream(optional)+30g strawberry crush + sugar as per taste.	3 min
3	Turmeric/ Garam Masala	A4	For 1L jar capacity : 300g assorted spice/turmric roasted & cooled. 0.7L jar capacity : 210g assorted spice/turmric roasted & cooled.	2 min
4	Wet Masala	A5	0.4L jar Capacity : 80g onion + 80g tomato.	2 min
5	Ginger Garlic Paste	A5	0.4L jar Capacity : 50g ginger + 50g garlic.	2 min
6	Tomato puree	A2/A3	For 2.0L / 1.5L Jar Capacity : 300g medium sized tomatoes cut in 4 pieces.	2 min
7	Lassi	A2/A3	For 2.0L / 1.5L Jar Capacity: 500g curd +salt/sugar(As per taste) + crushed ice.	1 min

OPERATING SPEEDS:For Wet/Dry/Chutney grinding, use speed '1' and '2' for 30 seconds, thereafter use speed '3' till you finish grinding. For juicing/blending use speed 1 and 2.

#### **GENERAL DECLARATIONS**

- This appliance can be used safely for household use only.
- Before using this appliance, please give your special attention to the safety precautions and thorougly clean the jars before first use

#### SAFETY PRECAUTIONS

- Place the appliance only on a flat, dry and stable surface.
- Keep the appliance away from sources of heat like gas or electric stoves.
- Make sure the voltage and the plug type are the same as your supply.
- The appliance is to be run only after assembling the jar unit and securing jar lid.
- Do not bend or put excessive pressure on the power cord or let the power cord hang over the edge of the table/slab or touch any hot surface.
- The appliance is not to be used if the power cord is damaged. Also, the power cord must be replaced by the manufacturer's service representative or similarly qualified person to avoid a hazard.
- Make sure the switch on the appliance is in the '0' position and each part is securely fit before operating it.

#### WARNING

- This appliance is not safe to be used by children or persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.
- Do not immerse the motor unit in water or try to clean the unit with running water as the motor unit, power cord, and plug should not encounter water/liquids.
- The chutney jar is fixed with chutney blade permanently. Do not attempt to remove it.
- Do not move the appliance during operation.
- Do not open the lid until the rotation of the blade stops completely.
- Do not touch food in the jar by hand. Always use the spatula provided in the box.
- Keep hands and utensils away from the moving parts while the appliance is in

- operation to prevent the possibility of severe personal injury or damage to the appliance. The spatula may be used to stir ingredients only when the machine is Do not run appliance with an empty iar.
- Never load the jar ingredients beyond the maximum indicated levels.

### **OPERATING INSTRUCTIONS**

- Ensure that all the blades are assembled on the jar.
- Care shall be taken when handling the sharp cutting blades, emptying jars and cleaning them.
- Switch off the appliance immediately when the motor stalls or you observe smoke coming from within.

#### **TURMERIC GRINDING**

- For best results, while grinding turmeric follow the instructions below: Roast whole turmeric in an open pan for a few minutes and then allow it to cool.
- Start by using the 'pulse' function to break the large pieces of turmeric into small ones and follow up by running the mixer on speed '3' to grind it to a fine powder.

#### **OVERLOAD PROTECTION**

- The appliance is fitted with a Circuit breaker protection /Overload protection to automatically shut off power mechanism to avoid motor damage on account of overloading.
- If the appliance stops due to overloading, then 'switch off' the Mixer and remove the excess load from the jar. Post-extraction of ingredients and pausing for 2-3 minutes; press the red toggle switch located at the bottom and restart.

#### **CLEANING AND MAINTENANCE**

- After usage, run the mixer grinder with warm water and a small quantity of detergent along with blade to dislodge food particles sticking under the washer (steel cap).
- Do not immerse jar collar or base of the mixer in water.
- The appliance may be cleaned with damp cloth and mild nonabrasive cleaner to remove any spots. Dry with clean soft cloth.
- Do not use abrasive cleaners on jars.

### TECHNICAL DATA \*\*\* (Info varies modelwise)

Wattage : 750W/ 650W/ 600W/

550W/ 500W

Power supply : 230 volts/50Hz, Ac Speed : 3 speed with Pulse

Rating : 60/30 minutes (5 minutes

ON/ 2 minutes OFF)

Note: \*\*\*Technical data mentioned is model specific.

#### WARRANTY TERMS AND CONDITIONS

Groupe SEB India (P) Ltd. ("Company") warrants to the purchaser of this Product that for a period of

- 1 year on product & 2 years on motor for 650W / 600W / 550W / 500W product.
- 2 year on product & 5 years on motor for 750W product.

Commencing from the date of purchase, the Company will repair or replace free of charge any part or parts of the product, during the above mentioned warranty period, should the Company be fully satisfied in its sole discretion that the defect/s is/are due to faulty material or defective workmanship only. The warranty will be governed by the following clauses:

- This warranty is valid only if this card is duly signed and stamped by our dealer and is produced along with the original customer's copy of the purchase bill.
- Warranty period starts from the date of purchase from our authorized dealer only.
- The Appliance has to be used with all normal care and maintenance and in accordance with instructions for use, recommended by the company, as enumerated in the instruction manual.
- The Appliance should not be repaired, tampered or altered by any agency or person other than an authorized company personnel or their service centers.
- The Appliances subject to normal wear & tear, misuse, neglect, accident including technical breakdown etc. or non compliance of the instructions given in the instruction manual, improper installation is not coverd by this warranty.
- Plastic Parts, which are breakable, are not covered under this warranty.
- The Appliance is meant for domestic use only.
- · The decision to repair or replacement

- of parts shall be at the sole discretion of the company. Unless the product part is non-repairable, replacement shall not be provided.
- Parts repaired or replaced under this warranty are warranted only for the remainder of the original warranty period, that is no fresh warranty period shall commence for the said replace/repaired part.
- Liability under terms of warranty is limited to the value of the repaires/replacement of the parts found to be defective with in the warranty period. All parts that would have to be replaced shall become the property of the company.
- The warranty shall not apply to replacement parts such as Carbon Brushes, Lid, Rubber Ring, Coupler, Shaft Blade. Bush Handle & Main Cords.
- The customer is responsible for bringing the defective product to the service centre/ manufacturer for servicing & collecting the same at his/ her own cost.
- Under the terms of warranty, installation, free service will be provided only within the municipal limits of the cities/towns where the company has its branches or authorized representatives. Service outside the municipal limits specified above will be provided after charging the actual to and fro traveling and incidental expenses, as prevailing from time to time.
- The decision of the company is final and binding on all matters arising out of this warranty.
- This warranty is issued at Delhi, and courts at Delhi shall have exclusive jurisdiction over matters by or following from this warranty. In case of any dispute, arising out of this the same shall be settled by an Arbitrator, In accordance with the provisions of Arbitration and conciliation Act, 1996.

	WARRANTY CARD				
	Model No:	Serial No:			
	C.M.No:	Date of Sale:			
	Tested By:	Remarks:			
AUTHORIZED DEALER/ FRANCHISEE					

## COMPANY'S AUTHORIZED PRICE LIST FOR SPARES IS AVAILABLE WITH SERVICE FRANCHISEE

Manufactured and Marketed by: Groupe SEB India (P) Ltd. Village Malkumajra, Paragna- Dharampur, Baddi Nalagarh Road, Dist. Solan (Himachal Pradesh) INDIA -173205

### FOR CUSTOMER FEEDBACK AND COMPLAINTS, PLEASE CONTACT:

Service Executive: Groupe SEB India (P) Ltd.

C-67, 3rd Floor,

DDA Sheds, Okhla Phase1,

New Delhi-110020, India

Tel: 011- 43684999, 011- 3368-4999 e-mail: maharajacare@groupeseb.com

Bis Website:- http://www.bis.gov.in

\*'Maharaja Whiteline' is registered trademark of Groupe SEB India Pvt Limited.





