

## WARRANTY TERMS AND CONDITIONS

The Company offers **1- year product warranty**, for repairing or replacing parts, free of cost against defect in manufacturing functional part subject to the following terms and conditions.

1. This warranty is valid only if this card is duly signed and stamped by our dealer and is produced along with the original customer's copy of the purchase bill.
2. Warranty period starts from the date of purchase from our authorized dealer only.
3. The Appliance has to be used with all normal care and maintenance and in accordance with instructions for use, recommended by the company, as enumerated in the instruction manual.
4. The Appliance should not be repaired, tampered or altered by any agency or person other than an authorised company personnel or their service centers.
5. Plastic and glass parts, which are breakable, are not covered under this warranty.
6. The Appliances subject to normal wear & tear, misuse, neglect, accident including technical breakdown etc. or non compliance of the instructions given in the instruction manual, improper installation is not covered by this warranty.
7. The customer is responsible for bringing the defective product to the service centre/manufacture for servicing and collecting the same at his/her own cost.
8. The Appliance is meant for domestic use only.
9. Parts repaired or replaced under this warranty are warranted only for the remainder of the original warranty period, that is no fresh warranty period shall commence for the said replaced/repared part.
10. Liability under terms of warranty is limited to the value of the repairs/replacement of the parts found to be defective with in the warranty period. All parts may have been replaced shall have been replaced shall become the property of the company.
11. Under the terms of warranty, installation, free service will be provided only within the municipal limits of the cities/towns where the company has its branches or authorized representatives. Service outside the municipal limits specified above will be provided after charging the actual to and fro traveling and incidental expenses, as prevailing from time to time.
12. The decision of the company is final and binding on all matters arising out of this warranty.
13. This warranty is issued at Delhi, and courts at Delhi shall have exclusive jurisdiction over matters by or following from this warranty. In case of any dispute, arising out of this the same shall be settled by an Arbitrator, In accordance with the provisions of Arbitration and conciliation Act, 1996.

### WARRANTY CARD

Model No RH-127 Serial No. ....

C.M.No. .... Date of Sale. ....

Owner's Name & Address. ....

Tested By. .... Remarks. ....

AUTHORIZED DEALER/FRANCHISEE

COMPANY'S AUTHORIZED PRICE LIST FOR SPARES AVAILABLE WITH SERVICE FRANCHISEE



**MAHARAJA  
SERVICE APP**

[www.maharajawhiteline.com](http://www.maharajawhiteline.com)

Follow us on:

SAFETY

IS:3029-20



CML-322235

### Marketed by:

Groupe SEB India (P) Ltd.

C-67, 3rd Floor, DDA Sheds, Okhla Phase 1, New Delhi-110020, India

**For customer feedback and complaints, please contact:**

**Service Executive**

Groupe SEB India (P) Ltd.

C-67, 3rd Floor, DDA Sheds, Okhla Phase 1, New Delhi-110020, India

Tel : 8860555777, ☎ : 011-43684999,

e-mail : [maharajacare@groupeseb.com](mailto:maharajacare@groupeseb.com)

'Maharaja Whiteline' is registered trademark of Groupe SEB India Pvt Limited.

# MAHARAJA<sup>®</sup> — WHITELINE —



nano carbon neo  
Room Heater

## INSTRUCTION MANUAL

## IMPORTANT PRECAUTIONS

1. Use heater only in upright position.
2. Keep away from inflammable liquid and gases.
3. Don't use heater in the immediate surroundings of bathing, shower or a swimming pool.
4. Always position the heater away from curtains, furniture and flammable materials. Ensure all the time there is an unrestricted air flow around the heater.
5. When in use power cord must not lie on the heater.
6. The heater must not be placed directly under a wall socket.
7. Don't cover the front with any cloth etc. This may cause fire.
8. Do not tamper the appliance or attempt to open the casing in cases of product failure or non function.
9. The heater should be at least 4.5 cm from wall and there should be 100 cm clean distance in front of grill.
10. Do not touch the Switch with wet hands.
11. Keep the heater out of the reach of children.
12. The user is not allowed to repair the power cord, if damaged or broken.
13. The appliance cannot be used with heater selector, timer or other fuse at the same time. To avoid fire accident, the surface of the heater should not be covered.

## TECHNICAL DATA

Model	RH-127
Power Supply	230V 50Hz, AC Single Phase
Wattage:	500W
Carbon Heating Tube	1 N (500 W )
Safety Device	Provided with a safety Tip Over Switch at the base which switches OFF the heater in case it tilts or falls.

## PARTS LIST

1. Front Grill
2. Right cover
3. Left cover
4. Carbon Tube
5. Switch



## FEATURES & SAFETY DEVICES

1. The Heater is provided with Heating position which enables you to use the Heater in different climatic conditions economically.
2. The Heater is provided with "UNIQUE SAFETY DEVICE" which switches OFF the heater if it tilts or falls. This safety device is provided at the base of the heater.
3. This Heater saves energy as it consumes very less electricity (500W), there by saving in electricity bills.
4. The Heater is having powder coated body which provides excellent corrosion resistance and it leads to much longer life in respect of both looks and strength.
5. Superior Carbon Technology.

## OPERATING INSTRUCTIONS

1. Keep the product in upright position.
2. Press The Switch Button On Position By Selected Switch.
3. Since the tube is made of Carbon, it needs 10-20 seconds to light up and heat.

## MAINTENANCE

To clean the Carbon Heater use a soft damp cloth, without detergents, after the cord has been disconnected and the unit has been allowed to cool. Store the heater in a dry place when not in use for extended period.