

11. The Company shall not be liable for any indirect, special, consequential, special, incidental, punitive, exemplary or economical damage or loss. The Company's liability under or in relation to this warranty shall be limited to the purchase price paid by the Customer as per valid tax invoice.

THIS WARRANTY IS NOT APPLICABLE IN ANY OF THE FOLLOWING CASES:

- 1) The signed & stamped warranty card or the tax invoice is not presented to the service personnel at the time of claiming or availing the warranty.
- 2) The product installation, use or maintenance is not done as per the instructions given in this instruction manual or as per common sense/understanding of usage of electric iron for such actions which are not specifically stated in this Instruction Manual.
- 3) If the original serial number of the Product is removed, tempered or altered.
- 4) Violation of any warranty terms and conditions mentioned above.
- 5) The warranty doesn't apply to:
 - a) Plastic parts, Main Cord and Scratches on Soleplate.
 - b) Normal wear and tear of the products and parts.
 - c) Damage due to water contamination.
 - d) Damages resulting from accidents, mishandling, improper usage, negligence on the part of consumer.
 - e) Fluctuation in the supply voltage or usage of any power supply other than as specified on the Box.
 - f) Compliant not registered at the Customer care centre of the Company by way of phone call, email or WhatsApp Chatbot within the warranty period.

WARRANTY CARD

Model No. DI-132 Serial No.

C.M.No. Date of Sale.

Owner's Name and Address.....

Tested By. Remarks.

AUTHORIZED DEALER/FRANCHISEE

COMPANY'S AUTHORIZED PRICE LIST FOR SPARES AVAILABLE WITH SERVICE FRANCHISEE



**MAHARAJA
WhatsApp**

Easy & Quickest Way to
Register a Complaint

www.maharajawhiteline.com

Follow us on:

Manufactured By:

M/s A,R Industries, Mauza Rampur Jattan,
VPO Dhakwala Moginand, Kala amb, Tehsil Nahan, Distt. Sirmaur, H.P. India 173030

For customer feedback and complaints, please contact:

Service Executive

Groupe SEB India (P) Ltd.

C-67, 3rd Floor, DDA Sheds, Okhla Phase 1, New Delhi-110020, India

Tel : 011- 43684999 8860555777

e-mail : maharajacare@groupeseb.com

'Maharaja Whiteline' is registered trademark of Groupe SEB India Pvt Limited.

**MAHARAJA[®]
— WHITELINE —**



**Glo
Dry Iron**

INSTRUCTION MANUAL

FEATURES

1. Swivel
2. Soleplate
3. Pilot Light
4. Temperature Selector
5. Main Lead
6. Heel Rest

Please read these instructions before operating and retain for future reference.

SAFETY INSTRUCTIONS

1. It is important that the iron is always supervised while it is switched on. Never leave the appliance unattended while it is connected to the main supply or on the ironing board.
2. Children should never be allowed to operate the iron. Keep children away from this appliance.
3. The iron gets very hot in use. Burns can occur from touching the hot parts of the appliance, therefore touch handle and knob only.
4. Make sure that the main lead is not touching the hot parts of the iron.
5. Always unplug the iron from the main supply socket.
 - When it is not in use.
 - In the event of malfunction during use.
 - Before cleaning the appliance.
6. Never unplug the appliance from the main supply socket by pulling the main lead. Take care that the main lead does not trail over the front of the work surface.
7. Repair of electrical appliance must only be performed by the skilled personnel. Improper repairs can result in considerable hazards for the user.
8. In case the iron fails to operate or is damaged, please contact an authorised service centre for all repairs. Ask your retailer for the address of an authorised centre.
9. In case the appliance is misused or operated in any manner other than described in these instructions for use, no liability will be under taken for possible damage.
10. If supply cord is damaged it must be replaced by our services agent. (Service Center) or similarly qualified person in order to avoid hazard.

OPERATING INSTRUCTIONS

1. Make sure that the applied voltage is same as the rating voltage and the socket has effective earth connection.
2. This iron is for household only.
3. Do not touch the hot metal part, avoid scalding.

Hints on Ironing

1. Always check first if the label with the ironing instruction is attached to the article to be ironed. Follow the ironing instruction as per label. Sort the garments into groups relating to the international dot symbols or to the type of fabric.

FABRIC GUIDE

- Synthetic fiber (lowest setting)
 - Silk, Wool (Medium Setting)
 - Cotton, Linen (Highest Setting)
2. Always begin with the fabrics which require the lowest setting.
 3. Before ironing sensitive fabrics check the material by ironing a small hidden part of the article to see whether it is sensitive to heat or not.
 4. It is best to iron the garments when they are still a little damp. Extremely dry garments are difficult to iron.
 5. Always position the iron on its heel rest when you interrupt ironing.

IRONING

1. Position the iron on its heel rest (6) and connect it to main supply socket.
2. Turn the temperature selector (4) to the desired setting (relating to the type of the fabric).
3. When the pilot light goes off and glows again you can start ironing.
4. The pilot light will cycle on and off during ironing. This has no effect on the ironing.
5. If you set the temperature control to the lower setting after ironing at the high temperature, do not recommence ironing before the pilot light glows again.
6. When ironing is finished, unplug the appliance from the main supply socket.



CLEANING AND MAINTENANCE

1. Before cleaning the iron, always make sure that the plug has been removed from the main supply socket.
2. Allow the iron to cool down before cleaning.
3. Never immerse the iron in water or liquid.
4. Wipe the iron with a soft and dry cloth.

OCCASIONAL CARE OF SOLEPLATE

1. Apply a small amount of paraffin to the soleplate (2) while the iron is still slightly warm. Remove the residues with a soft cloth.
2. To remove residue of starch, greases, etc... wipe the soleplate (2) with the damp cotton to which a small amount of vinegar may be added if required..
3. Do not use harsh abrasive cleaners.
4. Do not place the iron with the soleplate on to rough surface.

Storage:- Always store the iron on its heel rest (6).

TECHNICAL DATA

Wattage : 1100W
Power Supply : 230 V AC 50 Hz

FOR BIS CERTIFICATION DETAIL SEE
Website : www.bis.org.in

WARRANTY

GROUPE SEB INDIA PVT LIMITED ("Company") warrants that the Company shall rectify any manufacturing defect in the electric iron ("Product"), carry out such repair/replacement (as the case may be) free of charge during the warranty period of 2 (two) years. The Company shall in no event be replacing the product as a part of warranty unless and until there is an irreparable manufacturing defect in the product as decided by the technical team of the Company.

The period of availing warranty shall commence from the date of purchase as mentioned on the valid tax invoice or on Warranty card duly filled, signed & stamped by authorised dealer of the Company. The Company is not required to provide any services pertaining to the product after the expiry of said warranty period.

TERMS AND CONDITIONS OF WARRANTY:

1. This warranty shall be valid only if the product shall be used only as per the guidelines provided in this instruction manual. The product is to be used only for domestic purpose and not for any commercial, rental or profit generating activities.
2. This warranty can only be availed by the first purchaser of the product and is not transferable and non-assignable.
3. The Customer is required to register the complaint with the Customer Care Centre of the Company by way of phone call, email or WhatsApp Chatbot.
4. The customer must present the valid warranty card or the valid tax invoice as a pre-condition before availing the warranty for the product as well as any related spares in the absence of which the Company may refuse to provide any warranty services.
5. Any repair or replacement done on the Product or any parts of the product during the warranty period, will in no event extend the Warranty period. The Warranty period is limited as provided herein, irrespective of the period of the product was not in use, was not giving proper performance, was under breakdown or was under repair by Company's authorised service centre.
6. The Company/its Authorised Service Centre reserves the right to retain any part/component/ product replaced. The Company shall have exclusive right to replace the defective/unserviceable parts with the parts which may be new or refurbished free of charge during the warranty period.
7. Any repair or replacement carried out on the product or any part thereof by anyone other than authorised service centre, shall make this warranty void.
8. The Company shall provide Door-step service during the Warranty period. However, if the Product is located outside the municipal limits and serviceable area of Company's Authorised Service Centre, in such rare event the Company may refuse to provide Door-Step service and the Customer shall be required to bring the Product at the designated Service Centre of the Company or some other location within the municipal limits, at its own cost and expenses.
9. In case of any doubt regarding any conditions mentioned on this warranty card, including but not limited to authenticity of the Product, tax invoice, warranty card, part of the product etc, the decision of the Company shall be final and binding on the Customer.
10. The warranty is issued at New Delhi and courts at New Delhi shall have sole jurisdiction over matters covered or flowing from this warranty.