

WARRANTY CARD	
<b>Model No.</b>	EC-102
<b>Serial No.</b>	.....
<b>C.M.No.</b>	.....
<b>Date of Sale.</b>	.....
<b>Owner's Name and Address</b> .....	
.....	
.....	
<b>Tested By.</b>	<b>Remarks.</b>
.....	.....
<b>AUTHORIZED DEALER/FRANCHISEE</b>	

COMPANY'S AUTHORIZED PRICE LIST FOR SPARES AVAILABLE WITH SERVICE FRANCHISEE



**MAHARAJA**  
**WhatsApp**  
 Easy & Quickest Way to  
 Register a Complaint

[www.maharajawhiteline.com](http://www.maharajawhiteline.com)

Follow us on :

**Marketed By:** Groupe SEB India (P) Ltd.

C-67, 3rd Floor, DDA Sheds, Okhla Phase 1, New Delhi-110020, India

**For customer feedback and complaints, please contact:**

**Service Executive**

Groupe SEB India (P) Ltd.

C-67, 3rd Floor, DDA Sheds, Okhla Phase 1, New Delhi-110020, India


☎ 011- 43684999 📞 8860555777

✉ maharajacare@groupeseb.com

'Maharaja Whiteline' is registered trademark of Groupe SEB India Pvt Limited.

# MAHARAJA<sup>®</sup>

## —WHITELINE—




**Frisco**  
 Electric Chopper

### INSTRUCTION MANUAL

## Product Identification :

Serial No.	Parts Name
1	Push Button
2	Power Cord
3	Motor Housing
4	Bowl Cover
5	Chopping Blade
6	Whisking Disc
7	Bowl



### SAFETY RECOMMENDATIONS

1. Always keep the appliance out of the reach of children
2. Check that the voltage of the appliance corresponds to the voltage marked on your mains supply meter.
3. Always unplug the appliance after use and before washing.
4. Wait until the blade has completely stopped before removing the lid.
5. Handle the blade with care. It is extremely sharp.
6. After much usage, the blade will become blunt and should be changed.
7. Do not pull on the main body in water nor place it under running water.
8. If the power cord or the plugs are damaged, do not use your appliance.
9. If the power cord is damaged, it must be replaced by the manufacturer or its service agent in order to avoid a hazard.

### USING THE CHOPPER:

#### CHOPPING / WHISKING

1. Place the blade onto the axis of the Bowl and place the ingredients to be chopped / whisked.
2. Fit the cover (5) on to the Bowl by pressing it until it aligns into the place.
3. Place the main body on to the Bowl cover set by turning gently to push the Chopping blade / Whisking disc axis aligned to the motor unit axis.
4. Plug in the appliance.
5. Press the Push Button and hold it for chopping / Whisking to be started.
6. Release the Push button and wait for the chopping blade / whisking disc to stop.
7. Remove the main body by pressing the bowl cover and unlocking the bowl cover by pushing in the opposite direction to when it was assembled. Remove the blade carefully.

#### CLEANING

1. Always unplug the appliance.
2. Remove the Motor Housing (3) from the bowl & wipe it only with a damp cloth. Never place it in a dishwasher, immerse it in water or place it under running water.
3. Remove the Chopping Blade / Whisking disc carefully from the bowl.
4. The Bowl, the Chopping blade / Whisking disc, the Bowl cover can be washed under running water or in the dishwasher.

#### STORAGE

After use the Chopper can be stored by wrapping the mains lead around the main body.

#### TECHNICAL DATA

Wattage :	250W
Power Supply :	220 Volt, 50Hz, AC
Capacity :	800ml bowl
Speed :	Single speed with Hand Press
Motor Rating :	5min (1min ON, 1min OFF)
Plug :	2 Pin Plug

### WARNING

1. Any other servicing should be performed by an authorized service representative.
2. Do let the appliance rest at least 5 minutes before using it again!
3. Never misuse this chopper. Care is needed when handling cutting blades, especially when removing the blade from the Bowl, emptying the Bowl and during cleaning.

### WARRANTY TERMS AND CONDITIONS

GROUPE SEB INDIA PVT LIMITED ("Company") warrants that the Company shall rectify any manufacturing defect in the Electric Chopper ("Product"), carry out such repair/replacement (as the case may be) free of charge during the warranty period of 2 (two) years. The Company shall in no event be replacing the product as a part of warranty unless and until there is an irreparable manufacturing defect in the product as decided by the technical team of the Company. The period of availing warranty shall commence from the date of purchase as mentioned on the valid tax invoice or on Warranty card duly filled, signed & stamped by authorised dealer of the Company. The Company is not required to provide any services pertaining to the product after the expiry of said warranty period.

#### TERMS AND CONDITIONS OF WARRANTY:

1. This warranty shall be valid only if the product shall be used only as per the guidelines provided in this instruction manual. The product is to be used only for domestic purpose and not for any commercial, rental or profit generating activities.
2. This warranty can only be availed by the first purchaser of the product and is not transferable and non-assignable.
3. The Customer is required to register the complaint with the Customer Care Centre of the Company by way of phone call, email or WhatsApp Chatbot.
4. The customer must present the valid warranty card or the valid tax invoice as a pre-condition before available the warranty for the product as well as any related spares in the absence of which the Company may refuse to provide any warranty services.
5. Any repair or replacement done on the Product or any parts of the product during the warranty period, will in no event extend the Warranty period. The Warranty period is limited as provided herein, irrespective of the period of the product was not in use, was not giving proper performance, was under breakdown or was under repair by Company's authorised service centre.
6. The Company/its Authorised Service Centre reserves the right to retain any part/component/product replaced. The Company shall have exclusive right to replace the defective/unserviceable parts with the parts which may be new or refurbished free of charge during the warranty period.
7. Any repair or replacement carried out on the product or any part thereof by anyone other than authorised service centre, shall make this warranty void.
8. The Company shall provide Door-step service during the Warranty period. However, if the Product is located outside the municipal limits and serviceable area of Company's Authorised Service Centre, in such rare event the Company may refuse the provide Door-Step service and the Customer shall be required to bring the Product at the designated Service Centre of the Company or some other location within the municipal limits, at its own cost and expenses.
9. In case of any doubt regarding any conditions mentioned on this warranty card, including but not limited to authenticity of the Product, tax invoice, warranty card, part of the product etc, the decision of the Company shall be final and binding on the Customer.
10. The warranty is issued at New Delhi and courts at New Delhi shall have sole jurisdiction over matters covered or flowing from this warranty.
11. The Company shall not be liable for any indirect, special, consequential, special, incidental, punitive, exemplary or economical damage or loss. The Company's liability under or in relation to this warranty shall be limited to the purchase price paid by the Customer as per valid tax invoice.

#### THIS WARRANTY IS NOT APPLICABLE IN ANY OF THE FOLLOWING CASES:

- 1) The signed & stamped warranty card or the tax invoice is not presented to the service personnel at the time of claiming or availing the warranty.
- 2) The product installation, use or maintenance is not done as per the instructions given in this instruction manual or as per common sense/understanding of usage of Electric Chopper for such actions which are not specifically stated in this Instruction Manual.
- 3) If the original serial number of the Product is removed, tempered or altered.
- 4) Violation of any warranty terms and conditions mentioned above.
- 5) The warranty doesn't apply to:
  - a) Main Cord
  - b) Normal wear and tear of the products and parts.
  - c) Scratches, breakage or discoloration on the Plastic parts and blades.
  - d) Damages resulting from accidents, mishandling, improper usage, negligence on the part of consumer.
  - e) Fluctuation in the supply voltage or usage of any power supply other than as specified on the Box.
  - f) Compliant not registered at the Customer care centre of the Company by way of phone call, email or service app within the warranty period.